

## ArmourScan Overlay Replacement



1. Unplug ArmourScan.  
Remove 4 Small Phillips Screws



2. Firmly and slowly remove green ribbon cable.



3. Replace front panel. Make sure pins line up correctly.



4. Replace 4 small Phillips screws.  
Reconnect ArmourScan and test.

For Additional questions or support Contact our technical support department:

[Support@tekvisions.com](mailto:Support@tekvisions.com)

800.827.0127